V1connection™

This optional Bluetooth®-enabled module lets you wirelessly connect V1 to your Android™ device.

V1connection works with all V1s, but its full capability is available only from V1s with ESP (Check for the ESP logo on the front panel below the Control Knob). On pre-ESP V1s, or when using a pre-ESP Concealed Display or Remote Audio Adapter, your handheld will serve as a wireless remote display of all V1 front-panel warnings, but other functions and screens are unavailable.



V1connection, the app

For the current list of compatible devices, please go to **http://www.valentine1.com/v1info/v1connection/compatibility.asp**.

To download this necessary app, open the “Play Store” on your device and search for “V1connection, the app.”

Pairing

When the ignition is switched on, V1connection will power up in the Discovery mode, indicated by a slow blinking of the blue LED. Then follow the steps below:

1. Make sure Bluetooth is switched on in your device (it’s off by default in most devices to save battery life).
2. Bring the device to be paired close enough to V1connection to establish Bluetooth contact. When prompted for a passkey, enter 1234. The device will inform you when pairing is complete. The blue LED will continue to blink slowly.
3. Open the application on your device. When the app opens and the blue LED glows steadily, the connection to V1 is complete.

Wiring diagram

Supply 12v to V1connection through the RJ11 jack marked ACC on any V1 power source. Connecting through SAVVY®, as shown below, is one of the more common solutions.

See page 27 of the Owner's Manual for other diagrams. Install V1connection in place of the Concealed Display as shown on that page.



Contains FCC ID: T9J-RN42
Contains IC: 6514A-RN42

FCC and IC Requirements:
This device complies with Part 15 of the FCC rules and with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépassepas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.